



# Read Me First

## Powerware 5125 2200 VA UPS Internal Battery Connection Instructions

Use the following procedure to ensure proper battery operation before installing the UPS:

- 1** Verify that the UPS is off and unplugged.
- 2** Remove the UPS front panel.
- 3** Slide up and remove the metal battery cover.
- 4** Connect the internal battery connectors.  
**NOTE:** A small amount of arcing may occur when connecting the batteries. This is normal and does not damage the unit or present any safety concern.
- 5** Reinstall the metal battery cover.
- 6** Reinstall the UPS front panel.
- 7** Refer to the *Powerware 5125 Tower UPS (1000–2200 VA) User's Guide* for UPS installation instructions.

If the UPS requires any type of transportation in the future, disconnect the UPS internal battery connector using the above steps in reverse order. If you need additional assistance, refer to the user's guide for contact information.

